THE AVIATION POINT · THEAVIATIONPOINT.COM · THE AVIATION POINT · THEAVIATIONPOINT.COM

The Aviation Point

MS18029 — cover assembly (type S) and nut assembly for MS27212

Cover and Nut Assemblies for MS27212 Terminal Boards: part numbers and the data printed for each.

Specification

Item	Value
Type	Terminal board cover and nut
Status	Check the current issue before design use.

Part numbers

.138-32 3 part numbers

Part no.	Item	Thread	Knobs
MS18029-1S(N)	Cover assembly	.138-32	With knobs
MS18029-11S(N)	Cover assembly	.138-32	Without knobs
MS18029-21	Nut assembly	.138-32	—

.2500-28 3 part numbers

Part no.	Item	Thread	Knobs
MS18029-3S(N)	Cover assembly	.2500-28	With knobs
MS18029-13S(N)	Cover assembly	.2500-28	Without knobs
MS18029-23	Nut assembly	.2500-28	—

.1900-32 3 part numbers

Part no.	Item	Thread	Knobs
MS18029-2S(N)	Cover assembly	.1900-32	With knobs
MS18029-12S(N)	Cover assembly	.1900-32	Without knobs
MS18029-22	Nut assembly	.1900-32	—

How to read the part number

Part	Meaning
Format	MS18029-<dash>
Example	MS18029-1S8 — cover assembly with knobs for eight studs

Notes

- (N) is the number of studs; replace it with that number. Cover: plastic laminate, for the MS27212 terminal board.
- Catalogue data: the standard governs. Use the part the drawing, SRM or IPC calls for.

SOURCES · MS18029 — Cover and Nut Assemblies for MS27212 Terminal Boards

SCAN · OPEN THIS DATA SHEET
theaviationpoint.com/parts/electrical/ms18029/

Reference data. The aircraft manufacturer's documentation (SRM / IPC) takes precedence.